INTRODUCING REVOLUTIONARY NEW ALL-PURPOSE FLEXiO SPRAYERS.

WHATEVER YOU'RE PAINTING, WE HAVE THE PERFECT SPRAYER FOR IT.

FLEXiO 590

All-purpose indoor/outdoor paint sprayer with 9 speeds. Comes with sturdy storage case and second nozzle for fine-finishing.

FLEXiO 570

All-purpose indoor/outdoor paint sprayer with 2 speeds.

ANY COATING, ANY PROJECT, INDOORS OR OUTDOORS.

WAGNER FLEXiO SPRAYER

X-BOOST TURBINE

Powerful X-Boost Turbine™ is three times more powerful than traditional high-volume, low-pressure sprayers, enabling it to spray any coating, including unthinned paint.

iSPRAY TECHNOLOGY

Revolutionary iSpray® technology provides up to 60% more airflow to provide smooth, professional coverage with any coating.

X-Boost™ Power Dial adjusts air pressure for precise control of any coating.

horizontal or vertical nozzle adjustment

variable spray width control from 2" to 14"

QUIETER. LIGHTER. FASTER.

50% quieter and 20% lighter than traditional airless paint sprayers.



BRING ON THE NEXT PROJECT

Quick-change nozzle allows you to easily switch coatings and colors.



TIPS & TRICKS



INDOORS

- Use high-quality paint, stain and primer, and a high-quality indoor/outdoor sprayer.
- Prep before you start. Cover floors and furniture with a drop cloth. Pre-taped poly film is a great quick way to protect trim and windows.
- Use the right coating. A flat paint provides deep color; a glossy paint is easy to wipe stains from.
- Do a practice patch. Keep sprayer 6-8" away from the surface.
- Spray with smooth strokes, either up-and-down or left-to-right. Overlap each pass by about 50%.
- To reduce dust in the air, turn off ventilation, heating and AC systems while you spray.

OUTDOORS

- Remove debris and dirt. Consider using a pressure washer, but stay at least 12" away to avoid damaging your siding.
- Cover plants and bushes with a drop cloth.
- Tape and cover any surfaces not being painted (windows, trim, etc.)
- Spray in smooth strokes. Follow the grain of your sur face: vertical for fences, horizontal for siding.
- Keep sprayer 6-8" away from the surface.

© 2013 Wagner Spray Tech • WagnerFlexio.com